



### How to measure for Roman Blinds

1. First decide whether you want your roman blind to fit outside the window frame (outside recess) or inside the frame (inside recess).

2. Outside recess - measure the window width (A2 to B2). We would normally advise you to add 5 cm either side of the frame to give the total required width. Next measure the finished drop (C2 to D2) from the top of the roman blind to where you want it to end.

3. Inside recess - measure within the width of the frame and give us the measurement exactly A1 to B1. Do exactly the same for the drop measuring inside the window frame from C1 to D1.

Remember: On your order you need to let us know:

- What side you want the cord on?
- Whether your measurements are inside or outside recess?